

Radioactive Material Spills

Minor Spills (microcurie amounts)

1. Notify all persons in room.
2. Confine spill immediately.
3. Notify Radiation Safety Officer (RSO) at 817-272-2185.
4. Begin cleanup immediately.

Major Spills (millicurie amounts)

1. Notify all personnel to evacuate the room or area.
2. Make no attempt to clean up the spill.
3. Switch off all fans and vacate room or area.
4. Provide temporary barricade and warning signs.
5. Notify RSO at 817-272-2185.
6. Notify UTA Police Department (UTAPD) at 817-272-3003.

Emergency Phone Numbers

UTA EH&S Office, Radiation Safety Officer	817-272-2185
UTAPD, Emergency	817-272-3003